

ATTENTION

IF YOU INTEND TO RUN THE PIPEWORK VERTICALLY BEHIND THE BOILER, MOVE THE SCREWS ON THE FIXING JIG FROM THE DEFAULT POSITION (NO. 3) TO POSITION NO. 5

